

网管产品 - 功能 #3939

Rel_3.1.3_Pre1T3版本更新主控文件配置

2025-08-22 10:09 - 赵晓辉

状态:	进行中	开始日期:	2025-08-22
优先级:	普通	计划完成日期:	
指派给:	马党旗	% 完成:	0%
类别:		预期时间:	0.00 小时
目标版本:		耗时:	0.00 小时

描述 1. 修改SSB 频率 频点的介绍 <ConfigItem name="/du-cell:DU-CELL/FREQUENCY_CONFIG_DL/NR_DL_ABS_FREQ_POINT_SSB" isShow="1" showName="同步信道中心频率" canEdit="" showType="" range="" assoc="" isNum="" length="" isKey="" xpath="/du-cell:DU-CELL/FREQUENCY_CONFIG_DL/NR_DL_ABS_FREQ_POINT_SSB"></ConfigItem> <ConfigItem name="/du-cell:DU-CELL/FREQUENCY_CONFIG_DL/NR_DL_ABS_ARFCN_POINT_SSB" isShow="1" showName="同步信道中心频点" canEdit="" showType="" range="" assoc="" isNum="" length="" isKey="" xpath="/du-cell:DU-CELL/FREQUENCY_CONFIG_DL/NR_DL_ABS_ARFCN_POINT_SSB"></ConfigItem> 2. 删除 频选调度的高/低门限 <ConfigItem name="FSS_SINR_LOW_TH" isShow="1" showName="FSS 信噪比最低门限值" canEdit="" showType="" range="[-10,50]" assoc="" isNum="1" length="" isKey="" xpath="/du-cell:DU-CELL/SCHEDULER_CONFIG/FSS_SINR_LOW_TH"></ConfigItem> <ConfigItem name="FSS_SINR_HIGH_TH" isShow="1" showName="FSS 信噪比最高门限值" canEdit="" showType="" range="[-10,50]" assoc="" isNum="1" length="" isKey="" xpath="/du-cell:DU-CELL/SCHEDULER_CONFIG/FSS_SINR_HIGH_TH"></ConfigItem> 3. 添加频选调度功能：好，中，差点UE判断参数 <ConfigItem name="UL_PATHLOSS_GOOD_POINT_THRESHOLD" isShow="1" showName="好点门限" canEdit="1" showType="" range="[0,100]" assoc="" isNum="1" length="" isKey="" xpath="/du-cell:DU-CELL/SCHEDULER_CONFIG/CELL_UL_POWER_CONTROL_CFG/UL_PATHLOSS_GOOD_POINT_THRESHOLD"></ConfigItem> <ConfigItem name="UL_PATHLOSS_MID_POINT_THRESHOLD" isShow="1" showName="中点门限" canEdit="1" showType="" range="[0,100]" assoc="" isNum="1" length="" isKey="" xpath="/du-cell:DU-CELL/SCHEDULER_CONFIG/CELL_UL_POWER_CONTROL_CFG/UL_PATHLOSS_MID_POINT_THRESHOLD"></ConfigItem> <ConfigItem name="UL_PATHLOSS_BAD_POINT_THRESHOLD" isShow="1" showName="差点门限" canEdit="1" showType="" range="[0,100]" assoc="" isNum="1" length="" isKey="" xpath="/du-cell:DU-CELL/SCHEDULER_CONFIG/CELL_UL_POWER_CONTROL_CFG/UL_PATHLOSS_BAD_POINT_THRESHOLD"></ConfigItem> 4. 添加pusch 闭环功率控制开关，添加pusch 闭环功控类型两个参数 <ConfigItem name="INITIAL_BWP_PUSCH_COMMON/UL_POWER_CONTROL_SWITCH" isShow="1" showName="PUSCH 闭环功控开关" canEdit="1" showType="Combo" range="false=> 关闭,true=>打开" assoc="" isNum="1" length="" isKey="" rule="%d%2==0" special=['"must_be_an_even"]' xpath="/du-cell:DU-CELL/INITIAL_BWP/INITIAL_BWP_PUSCH_COMMON/UL_POWER_CONTROL_SWITCH"></ConfigItem> <ConfigItem name="INITIAL_BWP_PUSCH_COMMON/UL_POWER_CONTROL_TYPE" isShow="1" showName="PUSCH 功率控制方式" canEdit="0" showType="Combo" range="false=>绝对值,true=>累加" assoc="" isNum="1" length="" isKey="" rule="%d%2==0" special=['"must_be_an_even"]' xpath="/du-cell:DU-CELL/INITIAL_BWP/INITIAL_BWP_PUSCH_COMMON/UL_POWER_CONTROL_TYPE"></ConfigItem> 5. 删除初始BWP配置参数中的 循环前缀的参数。 <ConfigItem name="BWP_CP_TYPE" isShow="1" showName="循环前缀类型" canEdit="0" showType="Combo" range="false=>Normal CP,true=>Extend CP" assoc="" isNum="" length="" isKey="" xpath="/du-cell:DU-CELL/INITIAL_BWP/BWP_CP_TYPE"></ConfigItem>	
---	--

历史记录

- #1 - 2025-08-22 10:10 - 钱伯宁
- 状态从 新建 变更为 进行中
- 指派给从 钱伯宁 变更为 薛泽庆

LMT 已修改

- #2 - 2025-08-22 10:16 - 薛泽庆

-指派给 从 薛泽庆 变更为 马党旗

网管已修改